

SLATESAFETY BABD V2 Propel Connected Worker Safety Wearable Device User Manual


[Home](#) » [SLATESAFETY](#) » SLATESAFETY BABD V2 Propel Connected Worker Safety Wearable Device User Manual 

Contents [[hide](#)]

- [1 SLATESAFETY BABD V2 Propel Connected Worker Safety Wearable Device](#)
- [2 Device Specifications](#)
- [3 Device Specifications](#)
- [4 Accessories + What is Included in the Box](#)
- [5 Legal Information](#)
- [6 Proper Device Usage](#)
- [7 Charging](#)
- [8 Setup Information](#)
- [9 Usage Information](#)
- [10 Support Information](#)
- [11 Documents / Resources](#)
- [12 Related Posts](#)



SLATESAFETY BABD V2 Propel Connected Worker Safety Wearable Device



Device Specifications

General	
Chipset	ARM Cortex-M33
Memory	32 MB (Over 300 hrs of offline use)
Weight (band and strap)	82g
Dimensions	2.7 x 2.8 x 0.53 in. / 68.6 x 71.1 x 13.5 mm
Ruggedization	IP68, High impact polycarbonate plastic
Strap	Durable Polyester, Nylon hook and loop, Elastic rubber
Ports	Proprietary dual magnetic charging port
Operating Temperature, Humidity	-20C to +55C, 5% to 95% relative humidity (non-condensing)
Storage/ Charging Temp.	0C to +45C
Connectivity	
Bluetooth	Bluetooth® 5.3
Cellular Data	LTE-M / NB-IoT (subject to regional support)
GPS	L1 Band

Device Specifications

Sensors	
6-Axis IMU	Gyroscope, Accelerometer
Body Proximity Sensor	Advanced On Body detection
PPG Sensor	Industry-leading sensor that measures wide variety of biometric data
Feedback	
Vibration	High G-force haptic motor
LED	Quad RGB LED indicators
Battery	
Capacity	700 mAh, 3 Wh, Lithium-ion polymer, UL1642 Certified
Security	
Security	Arm TrustZone, End-to-end data encryption
Compatibility	
PPE	Designed to be worn underneath standard PPE equipment

Accessories + What is Included in the Box

Included Accessories	
Inside BAND V2 Box	BAND V2 CHARGER V2 Cable, CHARGER V2 AC/DC adapter, BAND V2 Information Booklet, STRAPV2

Accessories	
MULTI-CHARGER V2	High capacity charging system
GATEWAYV2	Network adapter for cell-denied or restricted areas
BEACON V2	Ambient environment monitoring, Collision Avoidance, Indoor location/z one tracking

CHARGER V2 Specifications	
Cable	4 ft, Ultra-Flexible Cable
AC/DC Adapter	In t: 100VAC – 240VAC 50/60Hz t: 6.2VDC A UL listed : ES 88

Legal Information

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any change or modification not expressly approved by SlateSafety could void the user's authority to operate equipment.

This device is not a medical device and is not designed or intended for use in the diagnosis of disease or other conditions, or in the cure, mitigation, treatment, or prevention of disease.

FCC ID: 2A357002

Contains FCC ID: 2A3579160

For Device Warranty Information, please visit: slatesafety.com/warranty

For Terms of Service, please visit: slatesafety.com/terms-of-service

For Privacy Notice, please visit: slatesafety.com/privacy-notice


FireHUD Inc. d.b.a SlateSafety BAND V2

Proper Device Usage



The BAND V2 should be worn on the upper arm with direct skin contact. For optimal performance, place the center of the device between the bicep and tricep muscles and, if possible, avoid tattoos. The strap should be tight enough so that the device doesn't move around easily on the arm, but loose enough as to not cut off blood.

Charging



To charge the BAND V2, there are two options:

1. Attach CHARGER V2 (included)
2. Insert device into MULTI CHARGER V2 (not included)

While charging, the device will display pulsing blue LEDs. After charge completion, the device will display solid magenta LEDs.

Setup Information

Important – Before device usage, ensure that the BAND V2 has been properly assigned to a User with a Loadout in the SlateSafety software, located at app.slatesafety.com.

Alerts -If Alert thresholds are set in the User's Loadout, an Alert will trigger when any Alert threshold is crossed. When an Alert is triggered the BAND V2 will notify the User with vibrations and LED feedback.

Return to Work– If Return-To-Work thresholds are set in the User’s Loadout and they have recently triggered an Alert, a Return-To-Work will trigger when all ReturnTo-Work thresholds are crossed. When a Return-ToWork is triggered, the BAND V2 will notify the User with two short vibrations and green LED feedback.

Usage Information

On Body Mode – The BAND V2 uses a combination of sensors to determine when the device is being worn. Once worn, the device will provide brief feedback to the User via one short vibration and one orange LED pulse.

Sleep Mode – When not being worn and not being charged the BAND V2 will go into a low power sleep mode in order to conserve battery. It will awaken automatically once placed on charger or on the arm.

Tap Alert – If enabled in the User’s Loadout, a User can trigger a Tap Alert by following the instructions located at slatesafety.com/tapalert. When successfully triggered, the device will provide feedback to the User via vibrations and LED.

Support Information

For additional support materials, or to open a support ticket please visit: slatesafety.com/support

For email support, please email: support@slatesafety.com

If you have any questions, comments, or concerns, please do not hesitate to reach out to a SlateSafety representative.

Documents / Resources

	SLATESAFETY BABD V2 Propel Connected Worker Safety Wearable Device [pdf] User Manual 002, 2A357002, BABD V2, Propel Connected Worker Safety Wearable Device, BABD V2 Propel Connected Worker Safety Wearable Device, Wearable Device
---	---

Related Posts



[HCO ADAMM-RSM Wearable Device User Guide](#)

ADAMM-RSM Wearable Device Quick Start Guide How to Use ADAMM-RSM Office: 585-471-8215 Email: clinicaltrials@healthcareoriginals.com
1 Pleasant St, Ste...



[Maggy Social Distancing Made Easy wearable device Instructions](#)

Social Distancing Made Easy wearable device Instructions Social Distancing Made Easy wearable device The winning team of the...



[POSTURE360 210805 PostureSense Wearable Device User Guide](#)

POSTURE360 210805 PostureSense Wearable Device Product overview This product is a wearable device that is inserted into a...



[pwc LRSM0005 IoT Wearable Device User Guide](#)

Contact Tracing Device End-User Guide What's in the box? How to use the device? 1. TURN ON Hold...